

# Machine Learning based virtual metrology in advanced process control for improved high product mix manufacturing

Srividya Jayaram, Sanghyun Choi, Nathan Greeneltch


Siemens EDA, Digital Industries Software

**SIEMENS**

# Outline





- Motivation
  - Background: High product mix manufacturing in semiconductor foundry
  - Application: Chemical vapor deposition (CVD)
  - New product introduction (NPI)
- Approach
  - Virtual metrology (VM) development and utilization for control system
  - Calibre® design feature extraction
  - Calibre® Fab Insight VM modeling
  - VM modeling with and without incorporating design features and FDC data
- Results
  - APC system: R2R control with VM model
  - Control simulation result of APC system
- Conclusion

# Background: High product mix manufacturing in semiconductor foundry



- Growing demand for **custom-designed products** from diverse customers requires increased manufacturing flexibility
- High product mix manufacturing involves coordination of various chambers and processes
- Complex operational challenges results in reduced yields and higher costs, requiring development of effective strategies

# Application: Chemical vapor deposition (CVD) - Challenges






Variation in deposition thickness in high product mix environment due to

- Device layout design
- Chamber condition drift

Design Features can influence film thickness by affecting key transistor parameters like threshold voltage and overlap capacitance, that impacts yield



# Application: Chemical vapor deposition (CVD) - Challenges




CVD Process variability (Drift in CVD film growth rate) during Preventive Maintenance (PM) cycles and chamber-to-chamber variations  
Caused by decreasing surface area and reactive gas consumption within the CVD chamber because of accumulated film thickness

PM cycles: the entire process cycle between PMs

Efficient management of PM cycle variation and chamber matching can help reduce fab line efficiency and throughput loss

# New product introduction (NPI)




**High Mix Production → Frequent New Product Introductions (NPI)**

- Complex setup, time-consuming if not optimized
- Challenges for traditional run-to-run (R2R) advanced process control (APC) methods

Machine learning (ML) based virtual metrology (VM) approach proposed as an effective process control solution

# Virtual metrology (VM) development and utilization for control system

Metrology used for monitoring wafers to update control models. Effective metrology systems can help achieve precision during CVD Process.



Reliance on metrology tools can

- Extend processing times
- Raising costs
- Trade-off between cost and quality


**Virtual metrology (VM)** optimizes control in the CVD process, striking a balance between cost and quality

- Traditional VM uses process chamber data, including fault detection and classification (FDC), to predict metrology results
- VM seamlessly integrates predictions into real-time, high-volume manufacturing control systems, especially in run-to-run (R2R) settings

# Digital Twin Product: Understanding impact of product design

Visualizing impact of product design features on the model using SHAP analysis

## Design extraction



+


## Process Characterization

Process

Metrology



## Fab Insights Model Analysis



Design, simulate, and verify products digitally


Leverage physical design understanding to capture sensitive product characteristics

- VM can utilize specific design features extracted for better predictions across various layouts and technologies  
**Extended VM model** for enhancing control performance especially high product mix manufacturing




# Calibre® Fab Insights - VM model overview

## Training dataset




## Feature selection




Shap analysis used to rank and select features (top N) for training to prevent model from overfitting

## Ensemble Model



Ensemble model based on LightGBM (Based on Decision tree algorithms)  
Focus on performance and scalability  
OPTUNA's hyperparameter optimization

## Final Virtual Metrology Model




# VM modeling with and without incorporating design features and FDC data

Data for modeling


- Tech nodes: 3
- Product: 70
- Chambers: 15
- 5 equipment units
- Each with 3 chambers

VM modeling: -  
Training: 70% - Testing: 30%




※ Specific thickness targets for each technology node have been omitted due to confidentiality concerns

# VM modeling with and without incorporating design features by product



VM model incorporates design features consistently exhibits significantly better performance


# VM modeling with and without incorporating FDC data by chamber



VM model incorporates FDC data exhibits better performance across the majority of segmented cases




# APC system: R2R control with VM model



## Advanced process control (APC) system, utilizing the VM model for run-to-run (R2R) control


- CVD process recipe is derived from the VM model, which integrates design features, fault detection and classification (FDC), and incoming measurements to achieve the target thickness
- After post-measurement, the prediction error calculated by comparing the predicted thickness with the actual thickness after processing
- If the error surpasses predefined rules, such as specifications or a 20% threshold, the VM model is triggered to update, incorporating additional data within a predefined time frame

# Control simulation result of APC system




The system effectively mitigates variations in the R2R deposition film thickness and accurately adjusts the thickness to the desired target value

# Control simulation result of APC system by chamber



Improvement in chamber-to-chamber thickness variation with the implementation of the APC system

# Control simulation result of APC system by product



Improvement in product-to-product thickness variation with the implementation of the APC system



# Conclusion

- Growing demand for custom-designed products from diverse customers requires increased manufacturing flexibility and frequent NPI
- ML based VM approach is proposed as an effective process control solution for high product mix manufacturing
  - Formulate VM model with incorporating design features and FDC data
  - Employ most advanced and optimized ML methodology to build VM model
  - Integrate VM model to APC system for R2R control
- Simulation results confirm the effectiveness of integrating the APC system with the VM model into the CVD process, particularly within a high product mix foundry fab
- Further R&D being done to enhance the solution to better align with the demands and requirements of foundry customers



**Contact:**

**[Srividya.Jayaram@siemens.com](mailto:Srividya.Jayaram@siemens.com)**